


OPENING DIMENSIONS

KURR104E

NOTE: Before performing any type of installation, cleaning, or removing a light bulb, unplug refrigerator or disconnect power.




Critical Dimensions:
A. 14¾" (37.5 cm) utility opening
B. 24" (60.96 cm) minimum opening width

- Height dimensions are shown with the leveling legs extended to the minimum height.
NOTE: When leveling legs are fully extended, add 5/8" (15 mm) to the height dimensions.
- If the floor of the opening is not level with the kitchen floor, shim the opening to make it level with the kitchen floor.

| | |
|----------|------------|
| Model | Door Swing |
| KURL104E | Left |
| KURR104E | Right |

LOCATION REQUIREMENTS



To ensure proper ventilation for your refrigerator, allow for a ¼" (6.35 mm) space on each side and at the top. When installing your refrigerator next to a fixed wall, leave 2½" (6.35 cm) minimum clearance on the hinge side to allow for the door to swing open.

NOTE: It is recommended that you do not install the refrigerator near an oven, radiator, or other heat source. Do not install in a location where the temperature will fall below 55°F (13°C). For best performance, do not install the refrigerator behind a cabinet door or block the base grille.