Riverside


Hawthorne Dining Room Assembly Instructions


Page 1 of 1

email: info@riverside-furniture.com

Made in China

Components and Hardware List







#23653 DINING BENCH

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Separate, count and check all parts against the Components and Hardware List above. Failure to use the correct length bolts in the proper locations may result in an unsafe product and could also cause damage to the parts being assembled.

- Step 1: Attach the Bottom Stretcher (C) between the two Columns (B) using the 3-1/4" long Allen Head Bolts(H), Spring Washers (I) and Flat Washers(K). Do not fully tighten until after Step 3.
- Step 2: Attach the Top Stretcher (D) between the two Columns using the 1-1/2" long Allen Head Bolts (E) Spring Washers (I) and Flat Washers (J). Pull all parts together snug and tighten Bolts with the Allen Wrench (L).
- Step 3: Carefully place the Bench Top (A) upside down on a soft surface such as a blanket or carpet. Position the assembled Stretchers and Columns on the Bench Top and attach the Columns end holes using the 2" Allen Head Bolts (F) and the middle holes using the 3" Allen Head Bolts (G), the Top Stretcher using the 1-1/2" Bolts (E) and all the same Washers as before. Tighten Bolts with the Allen Wrench (L).





WARNING

This BENCH is designed and intended for seating only. To prevent against potential injuries and structural failures, this bench should NEVER be used for other than its intended purpose.