


Item: BR1DATTNS

Assembly Instructions




Please visit our website for the most current instructions, assembly tips, to report damage or request parts. www.walkeredison.com


Revised 05/2023-V2

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver and hammer is required for the assembly of this product.



- V I. Power tools should not be used to assemble this product.

















Parts List




Part #	Description	Qty
1	Top panel	01 pc
2	left side panel	01 pc
3	Right side panel	01 pc
4	Bottom panel	01 pc
5	Back panel	01 pc
6	Foot	04 pcs
8	Drawer handle	01 pc
9	Drawer Front	01 pc



Part #	Description	Qty
13	Drawer bottom	01 pc
14	Drawer back	01 pc
15	Front / Back crossbeam	02 pcs
16	Side crossbeam	02 pcs
18	Wooden angle bracket	04 pcs
27	Drawer runner	02 pcs
32	Right drawer side	01 pc
41	Left drawer side	01 pc

Hardware List

A		Ø8*30mm	Wooden dowel	28 pcs
B		Ø4,0*25mm	Screw	18 pcs
C		Ø3,5*30mm	Screw	14 pcs
D		Ø4,0*40mm	Screw	15 pcs
E		Ø10*10	Nail	12 pcs
F		Ø10*20mm	Wooden dowel	06 pcs
G		Ø6*30mm	Wooden dowel	08 pcs
H		Ø7*60mm	Screw	08 pcs
I		4mm	Hex Key	01 pc
J		Ø8*40mm	Wooden dowel	02 pcs
K		Ø4,0*16mm	Screw	01 pcs
L			Wall anchor	01 pc
M			Washer	02 pcs
N		Ø6*35mm		01 pc




Tape measure and hammer recommended for assembly (not included)




Philips head screwdriver required for assembly (not included)

The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.


Step 1




Attention to the
dowel length:
Ø10*20mm




Insert wooden dowel (F) into part 27.




Step 2



Insert wooden dowel (F) into part 8.




Step 3





Please assemble on
a clean soft surface
to avoid damage.

Insert Wooden dowel (A) into parts (2), (3), (32), and (41).




Step 4




Secure parts (1) to part (2) and (3) with
screw (C) and Phillips head screwdriver.

Step 5




Secure parts (27) to part (2) and (3) with screw (B) and Phillips head screwdriver.

Step 6





Secure parts (4) to part (2) and (3) with screw (D) and Phillips head screwdriver.

Step 7




Insert Wooden dowel (A) and (G) into parts (15), and (16).

Step 8



Secure parts (6) to part (16).




Step 9



Please assemble on
a clean soft surface
to avoid damage.


Secure the assembled part to the part (4).

Step 10




Secure the assembled part to part (4)
with screw (D) and Phillips head screwdriver.

Step 11




Secure parts (15) to parts (6).
Use a object like a book to support part (15).

Step 12





Attach the assembled part to the parts (15)
and hold this parts while someone help
to remove de objects (books).

Step 13





Attach the assembled part to the part (4) without disassemble.

Step 14




Secure the assembled part to part (4) with screw (D) and Phillips head screwdriver.

Step 15




Attach the foot (6) to the base (4) using screw (H) and hex key (I).

Step 16




Step 17




Step 18

Name and address of the supplier and date of production.




Step 19




Attach part (9) to part (8), with screws (B) and Philips head screwdriver.

Step 20




Attach parts (41) and (32) to part (9) with screws (C) and Philips head screwdriver.

Step 21






Insert part (13) between parts (41) and (32).

Step 22



Attach part (14) to parts (41) and (32) with screws (C), and Phillips head screwdriver.





Step 23






Insert wooden dowel (A) into part (27).

Step 24

Insert wood dowel (J) on the inside of the drawer, with the drawer inside the unit after having passed the wood dowel that is in the drawer slide. The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.



Step 25



Attach part (L) with screw (K) and washer (M), in the frame of superior panel unit using Phillips head screwdriver.

K		Ø4,0*16mm	01
L			01
M			01

Step 26




WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.




With drilling machine make one hole in the wall, Insert part (N) in the hole. Secure part (L) with screw (D) and washer (M), in the wall.



D		01
M		01
N		01

Name and address information for the manufacturer responsible for the anti-tip hardware and date of production can be found on the label on the back of the furniture.



Assembly Complete!