


# ASSEMBLY INSTRUCTIONS

## STEP 1: POSITIONING THE TABLE COMPONENTS

WITH THE HELP OF ANOTHER PERSON, CAREFULLY TURN THE TABLE UPSIDE DOWN AND PLACE THE TABLETOP ON A FLAT, PROTECTED SURFACE. INSERT THE DOWELS INTO THE PRE-DRILLED HOLES ON THE TABLETOP. ALIGN THE LEG HOLES WITH THE DOWELS AS SHOWN IN DETAIL A. ONCE THE LEGS ARE IN POSITION, ATTACH THE METAL BRACKETS AS ILLUSTRATED IN DETAIL B.

*THE IMAGES ARE FOR REFERENCE ONLY.*



## STEP 2: INSERT SCREWS INTO THE LEGS

ALIGN THE HOLES ON THE LEGS WITH THE DOWELS AND TABLETOP. INSERT THE 1/4" X 3/4" CONNECTOR BOLT INTO THE LEG HOLES AS SHOWN IN DETAIL C. USE THE PROVIDED 5/32" HEX KEY TO TIGHTEN THE SCREWS ONLY INTO THE LEGS AT THIS STAGE.





DESCRIPTION	#
WOOD DOWEL 10 X 50	12
CONNECTOR BOLT 1/4" X 3/4"	32
HEX KEY 5/32"	1

# ASSEMBLY INSTRUCTIONS



## STEP 3: INSERT SCREWS INTO THE TABLETOP

AFTER SECURING THE LEGS, INSERT THE 1/4" X 3/4" CONNECTOR BOLT INTO THE HOLES ON THE TABLETOP SIDE, AS SHOWN IN DETAIL D. TIGHTEN THE SCREWS USING THE HEX KEY TO FIRMLY SECURE THE LEGS TO THE TABLETOP.



## STEP 4: FINAL CHECK

ENSURE THAT ALL SCREWS — BOTH IN THE LEGS AND TABLETOP — ARE PROPERLY TIGHTENED. CHECK THE TABLE FOR STABILITY BEFORE TURNING IT UPRIGHT AND PLACING IT IN ITS FINAL POSITION.



DESCRIPTION	#
WOOD DOWEL 10 X 50	12
CONNECTOR BOLT 1/4" X 3/4"	32
HEX KEY 5/32"	1