


# Item: BR60BRX6D-T

## Assembly Instructions






Please visit our website for the most current instructions, assembly tips, to report damage or request parts. [www.walkeredison.com](http://www.walkeredison.com)

Revised 11/2023-V1


# General assembly guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver, hammer and tape measure is required for the assembly of this product.



Tape measure

- VI. Power tools should not be used to assemble this product.





## VII. Maintenance Guide

To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.

1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.

# Parts List








The side drawer with WARNING LABEL, should be mounted in highest drawer.




Part #	Description	Qty
1	Top panel	01 pc
2	Left side panel	01 pc
3	Right side panel	01 pc
4	Bottom panel	01 pc
5	Division	01 pc
6	Large wood slider	06 pcs
7	Back panel	02 pcs
8	Back rail	01 pc
9	Foot	04 pcs
10	Central foot	01 pc


Part #	Description	Qty
11	Drawer handle	12 pcs
12	Center drawer front	02 pcs
13	Drawer front	04 pcs
14	Drawer bottom	06 pcs
15	Drawer back	06 pcs
17	Wood slider	06 pcs
18	Left drawer side	06 pcs
19	Right drawer side with warning	01 pc
21	Right drawer side	05 pc

# Hardware List


A		Ø8*30mm	Wooden dowel	45 pcs
B		Ø10*20mm	Wooden dowel	36 pcs
C		Ø4*25mm	Screw	60 pcs
D		Ø3,5*30mm	Screw	24 pcs
E		Ø4,0*40mm	Screw	10 pcs
F		10*7	Nail	35 pcs
G		Ø7*60mm	Screw	03 pcs
H		Ø6*31mm	Cam bolt	33 pcs
I		Ø15*11mm	Cam lock	33 pcs
J		15*15mm	Back panel metal plate	07 pcs
K		4mm	Hex Key	01 pc
L			Wall anchor	01 pc
M			Washer	02 pcs
N		Ø4,0*14mm	Screw	09 pc
O		Ø6*35mm	Plastic bush	01 pc



Hammer recommended for assembly (not included)







Philips head screwdriver required for assembly (not included)




Tape measure required for assembly (not included)


*The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.*

# Hardware List


P		Ø8*40mm	Wooden dowel	12 pcs
Q			Threaded foot insert	01 pc
R		Ø1/4*25mm	Threaded leveling foot	01 pc
S		Ø7*40mm	Screw	02 pcs
T		75*45*2mm	Metal plate	02 pcs



Hammer recommended for assembly (not included)





Philips head screwdriver required for assembly (not included)






Tape measure required for assembly (not included)

*The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.*

# Step 1





Attention to the  
dowel length:  
Ø10\*20mm






Insert wood dowel (B) into part 6 and 17.

# Step 2




Please assemble on  
a clean soft surface  
to avoid damage.





Insert wood dowel (A) into parts 2, 3, 5, 8, 9, 10, 18, 19 and 21.


# Step 3




1 - Ensure cam bolt is installed straight and not at an angle.  
 2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.




Attach cam bolt (H) into the holes in parts 1, 12, and 13 with Phillips head screwdriver.



# Step 4




Secure parts 17 to parts 2 and 3 with screw (C) and Phillips head screwdriver.



# Step 5


TOP




! Rotate part 5.

TOP

Secure parts 6 to part 5 with screw (C) and Phillips head screwdriver.




# Step 6




Attach parts 2 and 5 to part 1.


# Step 7




Align the opening in cam lock to the cam bolt and press into opening. Using a screwdriver, rotate the cam lock until it engages with the cam bolt and locks in place (anywhere between 90-180 degrees). Do not over-tighten the cam lock. Doing so may result in damaged or broken parts.



Insert Cam lock (l) in the hole of the part 2 and part 5, and attach with Phillips head screwdriver.




# Step 8




Attach part 8 to part 2.

# Step 9




Attach part 3 to part 8 and to part 1.

# Step 10



Insert Cam lock (I) into the holes in the part 3, and attach with Phillips head screwdriver.

# Step 11




Insert threaded foot insert (Q) into the hole in the part 10 and insert threaded leveling foot (R).

Q		01
R		01

Ø1/4\*25mm


# Step 12



Attach leg 9 and 10 to part 4 with bolt (G) and hex key (K).

G		03
Ø7*60mm		
K		01
4mm		


# Step 13




Attach Metal plate (T) to part 9 with bolt (S) and hex key (K).

K		01
4mm		
S		02
Ø7*40mm		
T		02
75*45*2mm		


# Step 14



Attach leg 9 with Sheet Metal, to part 4 with Screws (N) and Phillips head screwdriver.

N		08
Ø4,0*14mm		

# Step 15




Attach part 4 to parts 2, 3 and 5 with Screws (E) and Phillips head screwdriver.


E		09
Ø4,0*40mm		

# Step 16


Name and address of the supplier and date of production.



Secure back panel 7 to the dresser back with nails (F), back panel metal plate (J) and hammer.

F	 10*7	35
J	 15*15mm	07


# Step 17




Insert wood dowel (A) into the front hole in the wood sliders 6 and 17.

A	 Ø8*30mm	12
---	--	----


# Step 18



Attach part 12 to part 11 with screws (C) Phillips head screwdriver.  
 Attach part 13 to part 11 with screws (C) Phillips head screwdriver.





# Step 19




**WARNING**  
 Children have died from furniture tipover. To reduce the risk of furniture tipover:  
 • ALWAYS install Anti-tip device provided.  
 • NEVER put a TV on this product.  
 • NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.  
 • NEVER open more than one drawer at a time.  
 • Place heaviest items in the lowest drawers.  
 This is a permanent label. Do not remove!

Attach part 18 and 21 to part 12.  
 Attach part 18 and 21 to part 13.  
 Attach part 18 and 19 to part 13.


# Step 20




Insert Cam lock (I) into the holes in the parts 18, 19 and 21, and attach with Phillips head screwdriver.



# Step 21




Insert part 14 into groves and secure part 15 with screws (D) and Phillips head screwdriver.




# Step 22

The side drawer with WARNING LABEL, should be mounted in highest drawer.



Insert wood dowel (P) on the inside of all drawers, with the drawer inside the unit after having passed the wood dowel that is in the drawer slide. The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.




# Step 23

# WARNING


**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

**Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.**





## ! 1st





Attach part (L) with screw (N) and washer (M), in the frame of top panel unit using Phillips head screwdriver.




## ! 2nd

With drilling machine make one hole in the wall, insert part (O) in the hole. Secure part (L) with screw (E) and washer (M) in the wall using a Phillips head screwdriver.



E		01
L		01
M		02
N		01
O		01

Wall



Name and address information for the manufacturer responsible for the anti-tip hardware and date of production can be found on the label on the back of the furniture.

# Assembly Complete!

