


Item: BR5DATTD-R-T

Assembly Instructions






Please visit our website for the most current instructions, assembly tips, to report damage or request parts. www.walkerediton.com


Revised 10/2023-V1

General assembly guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A philips head screwdriver, hammer and tape measure is required for the assembly of this product.



- VI. Power tools should not be used to assemble this product.





VII. Maintenance Guide

To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.

1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.

Parts List






The side drawer with WARNING LABEL, should be mounted in highest drawer.




Part #	Description	Qty
1	Top panel	01 pc
2	Left side panel	01 pc
3	Right side panel	01 pc
4	Base	01 pc
5	Front rail	04 pcs
6	Large wood slider	10 pcs
7	Foot	02 pcs
8	Back panel	02 pcs
9	Drawer Front	05 pcs

Part #	Description	Qty
10	Drawer Front	05 pcs
11	Left drawer side	05 pcs
12	Right drawer side	04 pcs
13	Drawer back	05 pcs
14	Drawer Bottom	05 pcs
15	Right Drawer side with Warning	01 pc

Hardware List


A		Ø8*30mm	Wooden dowel	54 pcs
B		Ø10*20mm	Wooden dowel	40 pcs
C		Ø4,0*25mm	Screw	62 pcs
D		Ø3,5*30mm	Screw	28 pcs
E		Ø4,0*40mm	Screw	06 pcs
F		Ø10*10mm	Nail	36 pcs
I		Ø8*40mm	Wooden dowel	10 pcs
J		ø15*30mm	Cam bolt	26 pcs
K		ø15*10mm	Cam lock	26 pcs
L			Wall anchor	01 pc
M			Washer	02 pcs
N		Ø6*35mm	Plastic Bush	01 pc
O		Ø4*16mm	Screw	01 pc
P		Ø4,0*40mm	Screw	01 pc



Hammer recommended for assembly (not included)




Philips head screwdriver required for assembly (not included)




Tape measure required for assembly (not included)

The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.


Step 1




Attention to the
dowel size:
Ø10*20mm




Insert wood dowel (B) into part 6.




Step 2




Insert wood dowel (B)
into part 9.



Step 3






Insert wood dowel (A) into parts 2, 3, 5, 7, 11, 12 and 15.




Step 4


1 - Ensure cam bolt is installed straight and not at an angle.
 2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.




Fix the Cam bolt (J) in part 1 and 10 using a Philips head screwdriver.




Step 5




Secure part 6 to part 2 and 3 with screw (C) and Phillips head screwdriver.




Step 6




Attach parts 5 to parts 2 and 3, using screws (D) and Philips head screwdriver.




Step 7



Attach base 4 to body using screw (E) and Philips head screwdriver.





Step 8




Secure foot 7 to base 4 using screw (C) and Philips head screwdriver.

Step 9




Secure part 1 to body with Cam lock (K) using Phillips head screwdriver.

Step 10




Insert wood dowel (A) into parts 6.




Step 11


Name and address of the supplier and date of production.




Secure back panel 8 to body with nails (F) and hammer.




Step 12



Attach part 9 to part 10, with screws (C) and Philips head screwdriver.

C		20
		Ø4*25mm


Step 13




Attach parts 11, 12 and 15 to part 10 with Cam lock (K) and Philips head screwdriver.

K		20
		Cam lock

Step 14



Insert part 14 between parts 11 and 12.
Attach part 13 to parts 11 and 12 with screws(D), and Phillips head screwdriver.



Step 15



WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label. Do not remove!

The assembled drawer with this warning must be placed on top of the unit.



Insert wood dowel (I) on the inside of all drawers, with the drawer inside the unit after having passed the wood dowel that is in the drawer slide.

The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.




Step 16

WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.





! 1st

Attach part (L) with screw (O) and washer (M), in the frame of unit top panel using Phillips head screwdriver.




! 2nd

With drilling machine make one hole in the wall, insert part (M) in the hole. Secure part (K) with screw (O) and washer (L) in the wall using a Phillips head screwdriver.




Wall



L		01
M		02
N		01
O	 Ø4*16mm	01
P	 Ø4,0*40mm	01

Name and address information for the manufacturer responsible for the anti-tip hardware and date of production can be found on the label on the back of the furniture.

Step 17



Assembly Complete!