

DSB-150

Bluetooth® Wireless Speaker System

Français

Système de haut-parleurs sans fil Bluetooth®

MANUEL DE L'UTILISATEUR / INSTRUCTIONS DE SÉCURITÉ / INFORMATIONS SUR LA CONFORMITÉ

Español

Sistema de altavoces inalámbricos por Bluetooth®

MANUAL DEL PROPIETARIO/INSTRUCCIONES DE SEGURIDAD /INFORMACIÓN DE CUMPLIMIENTO

DENON®

FCC / IC Information

❑ FCC Information (For US customers)

1. IMPORTANT NOTICE: DO NOT MODIFY THIS PRODUCT

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modification not expressly approved by Denon may void your authority, granted by the FCC, to use the product. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. CAUTION

- To comply with FCC RF exposure compliance requirement, separation distance of at least 20 cm must be maintained between this product and all persons.
- This product and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

3. COMPLIANCE INFORMATION

- **Product Name : Bluetooth® Wireless Speaker System**
- **Model Number : DSB-150**
- **FCC ID : XN6 - DSB150**

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this product may not cause harmful interference, and (2) this product must accept any interference received, including interference that may cause undesired operation.

Denon Electronics (USA), LLC
(a D&M Holdings Company)
100 Corporate Drive
Mahwah, NJ 07430-2041
Tel. (201) 762-6665

4. NOTE

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the local retailer authorized to distribute this type of product or an experienced radio/TV technician for help.

❑ IC Information (For Canadian customers)

1. PRODUCT IC No: 8819A - DSB150

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this product may not cause harmful interference, and (2) this product must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus complies with Canadian ICES-003.

2. CAUTION

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

❑ Informations sur IC (pour les clients canadiens)

1. APPAREIL

IC No: 8819A - DSB150

Cet appareil est conforme aux normes d'Industrie du Canada applicables aux appareils exempts de licence RSS. L'utilisation de ce dispositif est autorisée seulement aux deux conditions suivantes : (1) il ne doit pas produire de brouillage, et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

2. ATTENTION

Afin de réduire le risque d'interférence aux autres utilisateurs, il faut choisir le type d'antenne et son gain de façon à ce que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne soit pas supérieure au niveau requis pour l'obtention d'une communication satisfaisante.

For Canadian customers: CAN ICES-3 (B)/NMB-3 (B)

❑ RF Exposure Information

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR).

Cet équipement est conforme aux normes d'exposition aux radiations FCC/IC définies pour un environnement non contrôlé et satisfait les directives d'exposition à la radiofréquence (RF) dans le supplément C des OET65 et RSS-102 des règles d'exposition à la fréquence radio (RF) IC. Cet équipement a de très faibles niveaux d'énergie RF qui sont jugés conformes sans test de taux d'absorption spécifique (SAR).

Read these safety instructions before operating the unit.

SAFETY PRECAUTIONS



CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.
IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings.
 Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the AC adapter from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.



WARNING : DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD

- The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have swallowed or placed inside any part of the body, seek immediate Medical attention.
- Do not keep the battery in a place exposed to direct sunlight or in places with extremely high temperatures, such as near a heater.
- Used batteries should be disposed of in accordance with the local regulations regarding battery disposal.



WARNINGS

NOTES ON USE

- Avoid high temperatures.
- Allow for sufficient heat dispersion when installed in a rack.
- Keep the unit free from moisture, water, and dust.
- Unplug the AC adapter when not using the unit for long periods of time.
- Do not let insecticides, benzene, and thinner come in contact with the unit.
- Never disassemble or modify the unit in any way.
- Naked flame sources such as lighted candles should not be placed on the unit.
- The apparatus shall not be exposed to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not handle the AC adapter with wet hands.
- When the switch is in the OFF (STANDBY) position, the equipment is not completely switched off from MAINS.
- The equipment shall be installed near the power supply so that the power supply is easily accessible.

CAUTION:
 To completely disconnect this product from the mains, disconnect the plug from the wall socket outlet. The mains plug is used to completely interrupt the power supply to the unit and must be within easy access by the user.

Introduction

Thank you for choosing DENON® and congratulations on your purchase of the DSB-150 wireless speaker system. The DSB-150 is a self-amplified stereo speaker system that uses Bluetooth® wireless communication to receive a signal from any standard Bluetooth equipped device capable of stereo audio transmission (A2DP).


Using the simple controls on the DSB-150, and its remote control, you can adjust the volume of the system or operate the basic music play back functions of your connected devices. An auxiliary analog input also allows you to connect any music source that has a standard 3.5mm connector to the DSB-150. We hope you'll enjoy it for years to come.

Features

- Outstanding stereo performance from dual high-performance Denon-designed 3½ inch speakers in separate acoustic chambers, vented for extended bass response
- Bluetooth wireless streaming from any compatible Bluetooth music player, phone, tablet or computer
- Tap-to-pair functionality for instant connection with any device that supports Near Field Communication (NFC)
- AptX codec for CD-like sound quality over Bluetooth
- Auxiliary input
- Easy-to-use controls
- Volume level display behind grille
- Remote control with music playback controls
- Headphone output
- Elegant styling with beautiful high-gloss finish

Unpacking and Setting Up Your DSB-150

Carefully unpack the system. If there is any sign of damage from transit, report it immediately to your dealer and/or delivery service. Keep the shipping carton and packing materials for future use. Be sure to keep your purchase receipt in a safe place, as it may be required for warranty purposes.



In the carton you should find the DSB-150, remote control, power supply and a power plug adapter

Placement

Your DSB-150 will sound great just about anywhere. If you put it near a wall or corner the bass response will be enhanced. Blocking the bass ports on the rear of the cabinet will reduce bass response.

Power Connection


Attach the power plug adapter plate to the power supply. Plug the power supply into the wall power outlet. Connect the other cable from the power supply to the power input on the back of the unit.

Service Connector

The service port is used for software updates only.

Reset Button


Returns the DSB-150 settings to the defaults values.




Controls


 **power** – There are three power states.


- ▶ **on** - the button is lit blue. The system is powered up.
- ▶ **standby** – button is lit red. The system is powered down, but will automatically turn on when a new audio signal appears from a connected device.
- ▶ **off** – button is not lit. The system is powered down completely and will not respond to audio signals.



A quick press of the button will toggle between on and standby states. Press and hold the button to turn the system off.

 **Bluetooth input** – Press to select the Bluetooth wireless input. The button blinks rapidly when pairing and stays lit when the system is connected to a Bluetooth device. See the “Bluetooth Details” section of this manual for more information.

 **auxiliary input** – press to select the auxiliary input. The top button lights when the auxiliary input is selected.


 **muting** – to mute the sound or restore it to the previous volume level. When the sound is muted, the button is lit.

 **volume down** – press to reduce volume.

 **volume up** – press to increase volume.

Volume Display


There is a 10-segment volume display on the front behind the grille. The display lights blue when volume adjustments are made. After a few seconds the display turns off. When the system receives a signal from the remote control, the bottom LED flickers.



Remote Control

The remote control has the same buttons as are on the top of the system, with the addition of playback control buttons that let you control your compatible Bluetooth devices:

- ▶|| Play /Pause
- Stop
- ◀◀ Skip back / fast reverse
- ▶▶ Skip forward / fast forward



Notes About the Remote

When you unpack your remote control there will be a plastic tab extending from the battery compartment. This keeps the battery from being depleted. Pull out this tab before using the remote control. Eventually you'll need to replace the remote battery. When the battery is depleted, the remote won't reliably operate the DSB-150. You will need to replace it with a new CR2025 3V lithium coin-type battery, available at many retailers.



When using the remote you should be able to see the DSB-150. Point the remote control at the front panel of the system when pressing the buttons. If the DSB-150 does not respond to the remote, try moving closer to the system. Operating range is specified to be 15 feet, $\pm 30^\circ$.


Bluetooth Details

Getting Started – Pairing

Before you can stream Bluetooth audio to your DSB-150, you have to pair it to your device.


To pair the DSB-150 to a device for the first time:

1. Go to Bluetooth settings on your device. Make sure the device's Bluetooth feature is set to "on".
2. Turn on the DSB-150 by pressing the  button. The button will light solid blue. The  button will begin to flash, indicating that the system is searching for a device with which to pair.




3. The DSB-150 has two ways to initiate pairing:

NFC (Near Field Communication) or “tap-to-pair”. The newest and easiest pairing method. If you have an NFC enabled device, simply place it gently on the top of the DSB-150. Your phone or tablet does the rest, and you can be playing audio within seconds.



Press and hold the **⌘** button on the top of the DSB-150, or on the remote, for 3 seconds. The **⌘** button on the top will begin to flash blue, indicating that the system is looking for your device.



Look at the Bluetooth list on your device. You may have to select “search for devices” for a new device to appear in the list of available devices. Once “DSB-150” appears in that list, simply select to pair.

When the **⌘** button on top lights solid blue, you are ready to go! Fire up your music and enjoy!

Once the DSB-150 is paired to a device, its Bluetooth address is stored in a ‘Paired List’ so it can hook up to that device easily in the future. The DSB-150 is capable of storing up to 8 different devices. Once that limit is exceeded, the oldest device is cleared so that a new one can be stored.


After the first pairing, the DSB-150 will automatically connect to your device when it is in range. The **⌘** button on top of the DSB-150 will light solid blue to indicate the system is ready to stream music from your connected device. If a song is already playing through the device, the DSB-150 will start playing.

Note: If the Bluetooth button is lit, but nothing is heard:

- 1 Check the device to make sure a selection is playing. Make sure your music is not paused.
- 2 Check the device and the DSB-150 to make sure their volume levels are up and MUTE is not enabled on either of them.

The DSB-150 will stay in pairing mode for up to 5 minutes, searching for a Bluetooth device (which must also be in pairing mode). If it does not find a device, the Bluetooth button will light red to indicate that it was not able to pair. To try pairing again, press and release the **RESET** button on the back of the DSB-150. The **⌘** button will begin to flash, indicating that the system is searching for a device with which to pair. If you are still having trouble, try moving the device closer to the DSB-150 and repeat the pairing process.


Connecting Headphones

Connect the headphone plug to the 3.5mm jack beside the  symbol. This turns off the DSB-150 internal speakers. If your headphones have a larger 1/4-inch plug you will need an adapter, available at many retailers.

Auxiliary Input

Press the **AUX** button on the top or on the remote control. The **AUX** button on the top will light blue.


The DSB-150 can accept an analog signal from a wide range of sources—from CD players to MP3 players, and even older legacy devices. You'll need a cable with a standard 3.5mm stereo mini plug to connect between the source and the auxiliary input on the left side of the system.



Note: The analog output signals from some sources can be fairly strong. If the volume level of the source device is turned up too high, it could overload the inputs of the DSB-150. This is unlikely to cause damage, but can cause distorted sound. Initially, set the volume of the source to a medium – low level, then turn it up as needed. If you hear distortion, turn down the device's volume control.

Wall Mounting the DSB-150

The DSB-150 can be wall mounted using the keyhole openings on the back of the system. Install two M5 or equivalent screws in the wall. They must be exactly $3\frac{15}{16}$ " (100mm) apart, and level with each other. Leave about $\frac{3}{16}$ " (5mm) of the screw shaft exposed so the head of the screw can engage the keyhole opening. Carefully position the DSB-150 keyhole openings over the screw head and set it in place. Be sure the cabinet is firmly mounted on the screw heads before you let go of the system.



Register your product online @ www.denon.com

www.denon.com

Denon is registered trademark of D&M Holdings Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by D&M Holdings Inc. is under license. Other trademarks and trade names are those of their respective owners.
© 2013 CSR plc and its group companies.

The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.

The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.