


CROSLEY





FURNITURE

Bar Stool

CF500424/CF500430



PART LIST

A	B	C	D	E
				
Back Frame 2 PCS	Seat Frame 2 PCS	Front Leg (L & R) 4 PCS	Side Stretcher (L & R) 4 PCS	Front Stretcher 2 PCS

HARDWARE LIST

#1	#2	#3	#4	#5
				
M6 X 80mm	M6 X 50mm	M6 X 40mm		
Long Bolt 8 PCS (Extra 2)	Bolt 8 PCS (Extra 2)	Short Bolt 6 PCS (Extra 2)	Spring Washer 22 PCS (Extra 2)	Flat Washer 22 PCS (Extra 2)
#6	#7			
				
	4 x 38mm			
Allen Wrench 1 PC	Screw 12 PCS			

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Step 1. Attach seat frame (part B) to back frame (part A) using long bolts (part #1), short bolts (part #3), spring washers (part #4), flat washers (part #5) and allen wrench (part #6).

NOTE: Do not tighten bolts at this time.


NOTE: Please ensure you are using short bolts (part #3) in center to prevent damage to back frame (part A).



Step 2. Attach front legs (part C) to seat frame (part B) using bolts (part #2), spring washers (part #4), flat washers (part #5) and allen wrench (part #6).

NOTE: Do not tighten bolts at this time.


NOTE: The front legs (part C) are marked "R" for right and "L" for left.




Step 3. Insert side stretchers (part D) into assembled unit (parts A & C). Insert front stretcher (part E) into front legs (part C).

NOTE: The side stretchers (part D) are marked "R" for right and "L" for left.

NOTE: If side stretchers (part D) are not flushed with back frame (part A) and front legs (part C), switch the front legs (part C).




Step 4. Finger-tighten bolts (part #2), do not overtighten. Secure stretchers (parts D & E) using screws (part #7) and phillips head screwdriver.



#7  x 6

Step 5. Carefully turn unit upright. Ensure unit is leveled and square then tighten all bolts using allen wrench (part #6). Repeat steps 1-5 for remaining stool.



PO#
MODEL#
CF500424/CF500430
MADE IN MALAYSIA