

## CLEANING INSTRUCTIONS

To ensure brewery-fresh flavor, it is recommended that the beer system be cleaned after every barrel or every two weeks to eliminate bacteria, yeast and beer stone build-up in the system. Below, you'll find instructions on how to properly and thoroughly clean your beer dispenser.

## SUPPLIES NEEDED:

- Cleaning Kit Includes cleaning pump jar (A), coupling washer (B), 4 oz. BLC line cleaning chemical (C), check ball lifter (D), cleaning brush (E) and spanner wrench (F) (Kit Part No. 63797, shown right)
- Buckets
- Water (warm and cold)



**CAUTION:** The chemicals used to clean beer lines are hazardous. Please follow all recommended safety instructions on the chemical's container.



- 1. Turn off the CO<sub>2</sub>, either at the CO<sub>2</sub> cylinder or at the air distributor.
- 2. Remove tapping device (keg coupler) from the barrel.
- 3. If tapping device contains a check ball, insert check ball lifter into the bottom of the coupler (Perlick Low Profile Coupler does not contain a check ball).
- 4. Place tapping device into a small bucket.
- 5. Using a spanner wrench, remove the beer faucet from the dispensing head.
- 6. Fill cleaning pump with warm water.
- 7. Attach cleaning pump jar connector with washer to where faucet was removed from dispensing head.
- 8. Pump the warm water through the system to remove all remaining beer from the system. Empty tapping device bucket and rinse out. Place tapping device back into the bucket.
- 9. Fill cleaning pump jar with water and cleaning chemical per the recommendations on the cleaning chemical container.
- 10. Pump cleaning solution into system, leaving about a 1/2 the solution in the cleaning pump jar.
- 11. Let stand 15 minutes, then pump remaining solution through the system
- 12. Using a cleaning brush, clean the exterior surfaces of the tapping device and rinse with clean fresh water
- 13. Rinse out cleaning pump jar with fresh water
- 14. Fill cleaning pump jar with clean warm water and pump entire jar through the system
- 15. Repeat step 13 using clean cold water
- 16. During the 15 minutes that the solution is in the system, mix a small container with water and cleaning chemical per the instructions on the cleaning chemical container and disassemble the faucet per faucet manufacturers recommendations and let soak in solution
- 17. Using cleaning brush, clean the components of the faucet
- 18. Rinse all components of the faucet in clean fresh water. Check all seals on the faucet for wear and replace if necessary
- 19. Reassemble faucet
- 20. Remove cleaning pump jar from dispensing tower connection and reinstall faucet using spanner wrench to tighten properly
- 21. Turn on CO2 and tap new keg