

Wireless Speaker

Enceinte sans fil

Altavoz inalámbrico

SRS-XB23

©2020 Sony Corporation
Printed in China / Imprimé en Chine
<https://www.sony.net/>



* 5 0 1 2 9 6 2 1 1 * (1)

English | Wireless Speaker

Before operating the unit, please read this guide thoroughly and retain it for future reference.
Please access the following URL and read the contents of the END USER LICENSE AGREEMENT.
https://rd1.sony.net/help/speaker/el20/h_uc/

Owner's Record

The serial number is located inside of the cap on the rear side of the product.
Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. SRS-XB23

Serial No. _____

CAUTION

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time. Do not expose the batteries to extreme low temperature conditions that may result in overheating and thermal runaway. Do not dismantle, open or shred secondary cells or batteries. In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice. Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions. After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance. Dispose of properly.

RECYCLING RECHARGEABLE BATTERIES

Rechargeable batteries are recyclable.
You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you.

For more information regarding recycling of rechargeable batteries, visit
<https://www.sony.com/electronics/eco/environmental-management>

Caution: Do not handle damaged or leaking rechargeable batteries.

Do not place this product close to medical devices

This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

For customers in the USA

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must not be co-located or operated in conjunction with any other antenna or transmitter.

If you have any questions about this product:

Visit: <https://www.sony.com/electronics/support>

Contact: Sony Customer Information Service Center at 1-800-222-7669

Write: Sony Customer Information Service Center 12451 Gateway Blvd., Fort Myers, FL 33913

Supplier's Declaration of Conformity

| | |
|---------------------|---|
| Trade Name : | SONY |
| Model : | SRS-XB23 |
| Responsible Party : | Sony Electronics Inc. |
| Address : | 16535 Via Espriello, San Diego, CA 92127 U.S.A. |
| Telephone Number : | 858-942-2230 |

This device complies with part 15 of FCC Rules and Innovation, Science and Economic Development Canada's licence-exempt RSS(5). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm (7 7/8 in) or more away from person's body.



Caution on charging



Inserting the USB plug while it is wet may cause a short circuit due to foreign matter or liquid (tap water, salt water, soft drinks, etc.) getting on the main unit or charging cable. This may cause malfunctions or abnormal overheating.

Never insert the USB plug while the main unit or charging cable is wet.

Precautions

On safety

- If your skin touches this product for a long time when the power is on, it may cause a low temperature injury.
- Important information such as the model name is located on the inner and outer surfaces of the cap on the rear side of the unit.
- **On placement**
 - To eliminate the risk of malfunctions, avoid the following locations when placing or leaving this unit.
 - A place subject to high temperatures, such as under direct sunlight or lighting equipment, near a heat source, or in a sauna
 - Inside a vehicle with the windows closed (especially in summertime)
 - A place subject to excessive dust
 - A place subject to strong vibration
 - Place this unit on a flat, level surface. When placed on a sloped surface, the unit may fall over or fall off the surface due to its own vibration, resulting in injuries, malfunctions, or performance degradation.
 - Depending on the conditions where this unit is placed, it may fall over or fall off the surface. Do not leave any valuables near the unit.
 - This unit is not anti-magnetic. Keep objects susceptible to magnetism (recorded tapes, watches, cash cards and credit cards with magnetic coding, etc.) away from the unit. When you carry around the unit, keep this in mind as well.

Others

- Do not use or leave the unit in an extremely cold or hot environment (temperature outside the range of 5 °C – 35 °C (41 °F – 95 °F)). If the unit is used or left in outside the above range, the unit may automatically stop to protect internal circuitry.
- At high temperature, the charging may stop or the volume may reduce to protect the battery.
- Even if you do not intend to use the unit for a long time, charge the battery to its full capacity once every 6 months to maintain its performance.

About the Voice Guidance

IMPORTANT: THE SOUND GUIDANCE IS AVAILABLE IN THIS PRODUCT ONLY IN ENGLISH

Depending on the status of the unit, the voice guidance outputs from the unit as follows.

- When entering pairing mode: "BLUETOOTH pairing"
- When establishing a BLUETOOTH connection: "BLUETOOTH connected"
- When disconnecting a BLUETOOTH connection: "BLUETOOTH disconnected"
- When pressing the BATT (battery) button to check the battery power during the unit is turned on: "Battery fully charged/Battery about 70%/Battery about 50%/Battery about 30%/Please charge"
- When pressing and holding the ST PAIR button during the Stereo Pair function: "Left/Right"

On copyrights

- Android, Google Play and other related marks and logos are trademarks of Google LLC.
- LDAC™ is a trademark of Sony Corporation.
- The BLUETOOTH® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.
- Apple, the Apple logo, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- USB Type-C® and USB-C® are trademarks of USB Implementers Forum.
- Other trademarks and trade names are those of their respective owners.
- ™ and ® marks are omitted in the documents.

Notes on waterproof and dust proof features (Read before using the unit)

Waterproof and dust proof performance of the unit

The unit, with the cap fastened securely, has a waterproof specification of IPX7* as specified in "Degree of protection against water immersion" of the IEC60529 "Ingress Protection Rating (IP Code)"*³, and a dust proof specification of IP6X*² as specified in "Degrees of protection against solid foreign objects"*.^{2,3}

Liquids that the waterproof performance specifications apply to

| | |
|----------------|--|
| Applicable | fresh water, tap water, pool water, salt water |
| Not applicable | liquids other than the above (soapy water, water with detergent or bath agents, shampoo, hot spring water, etc.) |

*1 IPX7 (Degree of protection against water immersion): For details, refer to the Help Guide.

*2 IP6X (Degrees of protection against dust): For details, refer to the Help Guide.


*3 The supplied accessories and the connectors of this unit (USB) are neither waterproof nor dust proof. To reduce the risk of fire or electric shocks, do not expose the unit to water or droplets while using either or both of the connectors (USB). Do not place a vase or any other liquid-filled container on the unit.

The waterproof and dust proof performance of the unit is based on our measurements under the conditions herein described. Note that malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.

To avoid deterioration of waterproof and dust proof performance

Check the following and use the unit correctly.

- The unit passes the drop test from 1.22 m (4 ft) on plywood of 5 cm (2 in) thickness conforming to MIL-STD810H Method 516.8-Shock. However, this does not guarantee no damage, no breakdown, or waterproof and dust proof performance in all conditions. Deformation or damage from dropping the unit or subjecting it to mechanical shock may cause deterioration of the waterproof and dust proof performance.
- This unit does not have a design that is resistant to water pressure. Use of the unit in a location where high water pressure is applied, such as in the shower, may cause a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.
- Handle the cap with care. The cap plays a very important role in maintenance of the waterproof and dust proof performance. When using the unit, make sure that the cap is closed completely. When closing the cap, be careful not to allow foreign objects inside. If the cap is not closed completely, the waterproof and dust proof performance may deteriorate and may cause a malfunction of the unit as a result of water or dust particles entering the unit.



How to care for the unit

Although the fabric part of the unit has water repellent treatment applied, you can use the unit more comfortably and for a longer period of time by following the maintenance procedure below.

- If the surface of the unit gets dirty in the following cases, wash the unit with fresh water (tap water, etc.) promptly to remove the dirt. Leaving dirt on its surface may cause the fabric part or the passive radiator section to discolor or deteriorate, or the unit to malfunction.
- When salt, sand, etc. is stuck on the unit after using it on a beach, pool side, etc.
- When the unit is stained with foreign substances (sunscreen, suntan oil, etc.)
- If the unit gets wet, wipe off the moisture using a dry soft cloth immediately. In addition, dry the unit in an airy place until no moisture remains.
- The sound quality may change when water enters the speaker or passive radiator section of the unit. It is not malfunction. Wipe off the moisture on its surface, and put the unit on a dry soft cloth to drain the collected water inside the unit. Then, dry the unit in an airy place until no moisture remains.

Note

- If the surface of the unit gets dirty, do not use detergent, thinner, benzene, alcohol, etc. to clean the unit because it will affect the water repellent function of the fabric part of the unit.
- Especially in cold regions, be sure to wipe off the moisture after using the unit. Leaving moisture on its surface may cause the unit to freeze and malfunction.
- If sand grains, etc. enter the fabric or other part of the unit, remove them carefully. Never use a vacuum cleaner, etc. on the unit. It may cause damage of the speaker section or other part of the unit.

Notes on the License

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software.
Please access the following URL and read the contents of the license.
<https://rd1.sony.net/help/speaker/sl/20/>



Notice on GNU GPL/LGPL applied software

This product contains software that is subject to the following GNU General Public License (hereinafter referred to as "GPL") or GNU Lesser General Public License (hereinafter referred to as "LGPL"). These establish that customers have the right to acquire, modify, and redistribute the source code of said software in accordance with the terms of the GPL or LGPL supplied. The source code for the above-listed software is available on the Web.
To download, please access the following URL then select the model name "SRS-XB23".
[URL: https://oss.sony.net/Products/Linux/](https://oss.sony.net/Products/Linux/)
Please note that Sony cannot answer or respond to any inquiries regarding the content of the source code.

Specifications

Speaker section

Full range unit Approx. 42 mm × 51 mm (1 11/16 in × 2 1/8 in) (2)
Enclosure type Passive radiator model

BLUETOOTH

Communication System

BLUETOOTH Specification version 5.0

Maximum communication range Line of sight approx. 30 m (98 ft)*¹

Frequency band 2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Modulation method FHSS

Compatible BLUETOOTH Profiles*²

A2DP (Advanced Audio Distribution Profile)

AVRCP (Audio Video Remote Control Profile)

HSP (Headset Profile)

HFP (Hands-free Profile)

Supported Codec*³

SBC (Subband Codec)

AAC (Advanced Audio Coding)

LDAC

Transmission range (A2DP) 20 Hz - 20,000 Hz (Sampling frequency 44.1 kHz)

*¹ The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.

*² BLUETOOTH standard profiles indicate the purpose of BLUETOOTH communications between devices.

*³ Codec: Audio signal compression and conversion format

Note

Depending on the network environment, there may be an interruption at the high bitrate transmission.

Microphone

Type Electret condenser

Directional characteristic Omni directional

Effective frequency range 100 Hz - 7,000 Hz

Amplifier section

POWER OUTPUT AND TOTAL HARMONIC DISTORTION:

With 4 ohms loads, both channels driven, from 100 Hz - 10,000 Hz; rated 4 watts per channel minimum RMS power at stereo mode, with no more than 1% total harmonic distortion from


Liquides auxquels s'applique la notion d'étanchéité à l'eau

| | |
|---|---|
| Champ d'application | eau fraîche, eau du robinet, eau de piscine, eau salée |
| Hors du champ d'application | liquides autres que ceux mentionnés ci-dessus (eau savonneuse, eau avec détergent ou produits de bain, shampoing, eau de source chaude, etc.) |
| * IPX7 (degré de protection contre l'immersion dans l'eau) : pour plus d'informations, consultez le Guide d'aide. | |
| * IP6X (degré de protection contre la poussière) : pour plus d'informations, consultez le Guide d'aide. | |
| * Les connecteurs et accessoires de cet appareil fournis (USB) ne sont pas étanches ni résistants aux particules de poussière. Pour réduire le risque d'incendie ou d'électrocution, n'exposez pas l'appareil à des éclaboussures ou des gouttes d'eau lorsque vous utilisez un ou les deux connecteurs (USB). Ne posez pas sur l'appareil des objets remplis de liquides, notamment des vases. | |
| L'étanchéité à l'eau et l'étanchéité aux poussières de l'appareil sont fondées sur nos mesures réalisées dans les conditions décrites ici. N'oubliez pas que la garantie ne couvre pas les défaillances consécutives à l'immersion dans l'eau ou l'intrusion de poussières provenant d'un mauvais emploi par l'utilisateur. | |

Pour éviter la détérioration de l'étanchéité à l'eau et de l'étanchéité aux poussières

Vérifiez les points suivants et utilisez correctement l'appareil.

- L'appareil a réussi le test de chute de 1,22 m (4 pi) sur du contreplaqué d'une épaisseur de 5 cm (2 po), conformément à la norme MIL-STD810H Method 516.8-Shock. Cela ne garantit toutefois pas l'absence de dommage de panne, l'étanchéité à l'eau et l'étanchéité aux poussières dans toutes les conditions. Toute déformation ou dommage dû à la chute de l'appareil ou à une exposition à des chocs mécaniques peut entraîner la détérioration de l'étanchéité à l'eau et l'étanchéité aux poussières.
- De par sa conception, cet appareil ne résiste pas à la pression de l'eau. L'utilisation de l'appareil dans un endroit où une haute pression d'eau est appliquée, comme sous la douche, peut provoquer un dysfonctionnement.
- Ne versez pas d'eau très chaude et ne soufflez pas de l'air chaud provenant d'un séche-cheveux ou d'un autre appareil, directement sur l'appareil. En outre, n'utilisez jamais l'appareil dans un endroit soumis à des températures élevées, tel qu'à proximité d'une source de chaleur ou dans un sauna.
- Manipulez le capuchon avec soin. Le capuchon joue un rôle très important pour préserver l'étanchéité à l'eau et l'étanchéité aux poussières. Lorsque vous utilisez l'appareil, assurez-vous que le capuchon est complètement fermé. Quand vous fermez le capuchon, veillez à ne laisser aucun corps étranger pénétrer à l'intérieur. Si le capuchon n'est pas complètement fermé, l'étanchéité à l'eau et l'étanchéité aux poussières risquent de se détériorer et de provoquer une défaillance de l'appareil en raison de la pénétration de l'eau ou de particules de poussière à l'intérieur de celui-ci.



Comment prendre soin de l'appareil

Bien qu'un traitement repoussant l'eau ait été appliqué à la partie en tissu de l'appareil, nous vous recommandons de suivre la procédure d'entretien ci-dessous pour pouvoir utiliser l'appareil plus confortablement et plus longtemps.

- Si la surface de l'appareil est encrassee d'une des manières suivantes, lavez l'appareil à l'eau claire (eau du robinet, etc.) immédiatement pour éliminer la saleté. Si vous laissez des saletés sur la surface, la partie en tissu ou du radiateur passif peut se décolorer ou se détériorer, ou bien l'appareil risque de ne plus fonctionner correctement.
Ex.
 - Si du sel, du sable, etc. adhère sur l'appareil après une utilisation sur la plage ou au bord de la piscine, etc.
 - Si l'appareil est tâché par des corps étrangers (crème solaire, huile de bronzeage, etc.)
- Si l'appareil est mouillé, éliminez immédiatement l'humidité en utilisant une serviette douce et sèche. Laissez aussi sécher l'appareil dans un endroit bien aéré jusqu'à ce que l'humidité disparaîtse.
- La qualité du son peut changer lorsque de l'eau pénètre dans la partie enceinte ou la partie du radiateur passif de l'appareil. Cela ne constitue pas un dysfonctionnement. Essuyez l'humidité sur sa surface, puis placez l'appareil sur un chiffon doux et sec pour évacuer l'eau recueillie à l'intérieur de l'appareil. Ensuite, laissez aussi sécher l'appareil dans un endroit bien aéré jusqu'à ce que l'humidité disparaîtse.

Remarques

Ce produit contient un logiciel qui Sony utilise dans le cadre d'un accord de licence avec le propriétaire de ses droits d'auteur. Nous sommes tenus d'annoncer le contenu de l'accord aux clients à la demande du titulaire du droit d'auteur pour le logiciel.

Veuillez accéder à l'URL suivante et lire le contenu de la licence.
<https://rd1.sony.net/help/speaker/sl/20/>



Avis sur le logiciel GNU GPL/LGPL appliquée

Ce produit contient un logiciel qui est soumis à la licence publique générale GNU suivante (ci-après dénommée « GPL ») ou à la licence publique générale limitée GNU (ci-après dénommée « LGPL »). Elles établissent que les clients ont le droit d'acquérir, de modifier et de redistribuer le code source dudit logiciel conformément aux dispositions de la licence GPL ou LGPL fournie. Le code source du logiciel indiqué ci-dessus est disponible sur internet.

Pour le télécharger, accédez à l'URL suivante, puis sélectionnez le nom du modèle « SRS-XB23 ». URL : <http://oss.sony.net/Products/Linux/>

Veuillez noter que Sony ne peut répondre ni répondre à toute question concernant le contenu du code source.

Spécifications

Section enceintes

Appareil de pleine gamme

Environ 42 mm x 51 mm (1 1/16 in x 2 1/8 in) (2)

Type d'enceinte acoustique

Modèle de radiateur passif

BLUETOOTH

Système de communication

Spécification BLUETOOTH version 5.0

Portée maximale des communications

Environ 30 m (98 pi) en ligne directe*

Bande de fréquences

Bandes 2,4 GHz (2,4000 GHz - 2,4835 GHz)

Méthode de modulation

FHSS

Profils BLUETOOTH compatibles*

A2DP (Advanced Audio Distribution Profile)

AVRCP (Audio Video Remote Control Profile)

HSP (Headset Profile)

HFP (Hands-free Profile)

Codecs pris en charge*

SBC (Subband Codec)

AAC (Advanced Audio Coding)

LDAC

Plage de transmission (A2DP)

20 Hz - 20 000 Hz (fréquence d'échantillonnage 44,1 kHz)

* La portée réelle variera selon des facteurs tels que les obstacles entre les dispositifs, les champs magnétiques autour d'un four à micro-ondes, l'électricité statique, la sensibilité de la réception, la performance de l'antenne, le système d'exploitation, le logiciel d'application, etc.

*2 Les profils BLUETOOTH standard indiquent le but des communications BLUETOOTH entre les dispositifs.

*3 Codec : format de compression et de conversion des signaux audio

Remarque

La transmission à un débit binaire élevé peut être interrompue en fonction de l'environnement réseau.

Microphone

Type Condensateur à électret

Caractéristiques directionnelles Omnidirectionnel

Plage de fréquences efficace 100 Hz - 7 000 Hz

Section amplificateur

PUISSEUR DE SORTIE ET DISTORSION HARMONIQUE TOTALE :

Avec des charges de 4 ohms, les deux canaux étant alimentés, de 100 Hz à 10 000 Hz: puissance efficace RMS minimale de 4 watts par canal en mode stéréo, avec une distorsion harmonique totale inférieure ou égale à 1%, de 250 milliwatts à la puissance de sortie nominale.

Généralités

Alimentation

5 V CC (lors de l'utilisation d'un adaptateur CA USB disponible sur le marché, capable de délivrer un courant de 1,5 A) ou lors de l'utilisation de la pile au lithium-ion intégrée

Cycle de vie de la batterie au lithium-ion (lecture par une connexion BLUETOOTH)

Environ 12 heures*4

Environ 10 heures*5

Environ 3 heures*6

Dimensions (parties saillantes et commandes comprises)

Environ 76 mm (3 po) de dia. x 218 mm (8 5/8 po) (H)

Masse Environ 580 g (1 lb 5 oz) y compris la pile

Accessoire fourni Câble USB Type-C® (USB-A vers USB-C® / max. 1,5 A) (1)

Sangle (1) (fixé à l'appareil)

*4 Valeur mesurée obtenue en lisant notre source musicale spécifique à un niveau de volume de l'appareil réglé sur 34, le mode sonore réglé sur STAMINA.

*5 Valeur mesurée obtenue en lisant notre source musicale spécifique à un niveau de volume de l'appareil réglé sur 31 et avec les réglages d'usine par défaut (mode sonore : EXTRA BASS).

*6 Valeur mesurée obtenue en lisant notre source musicale spécifique à un niveau de volume de l'appareil réglé sur maximum et avec les réglages d'usine par défaut (mode sonore : EXTRA BASS).

*7 La durée de performance actuelle peut varier de celle indiquée en fonction du volume, des musiques lues, de la température ambiante et des conditions d'utilisation.

Configuration requise pour le chargement de la pile via USB

Utilisation d'un adaptateur secteur USB disponible sur le marché, capable de délivrer un courant de 1,5 A

Modèles de iPhone/iPod compatibles

iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6, iPhone 6 Plus, iPhone 5s, iPod touch (6e génération) L'appareil est compatible avec iOS 10.0 ou version ultérieure.

La conception et les caractéristiques sont sujettes à modifications sans préavis.

Español

Altavoz inalámbrico

Antes de utilizar la unidad, lea detenidamente esta guía y guárdela para futuras consultas. Acceda a la URL siguiente y lea el contenido del CONTRATO DE LICENCIA DE USUARIO FINAL. https://rd1.sony.net/help/speaker/el20/h_ue/

Registro del propietario

El número de serie se encuentra en el interior de la tapa en la parte trasera del producto. Anote el número de serie en el espacio provisto a continuación. Consultelo cuando llame a su distribuidor Sony en relación con este producto.

N.º de modelo SRS-XB23

N.º de serie

PRECAUCIÓN

No sitúe el aparato en un espacio cerrado, como una estantería o un armario empotrado.

No exponga las baterías (el paquete de baterías o las baterías instaladas) a un calor excesivo como el sol directo, fuego o similar durante un período prolongado. No exponga las baterías a condiciones de temperaturas extremadamente bajas que pueden provocar sobrecalentamiento y fugas térmicas. No desarمه, abra, ni tire las baterías. En el caso de que una batería gotee, no permita que el líquido entre en contacto con la piel o los ojos. Si se ha producido contacto, lave la zona afectada con abundante agua y acuda a un médico. Las baterías deberán cargarse antes de utilizarse. Utilice siempre el cargador correcto y consulte las instrucciones del fabricante o el manual del equipo para obtener las instrucciones de carga adecuadas. Después de largos períodos de almacenamiento, puede ser necesario cargar y descargar las baterías varias veces para obtener el máximo rendimiento. Elimínelas de forma adecuada.

RECICLADO DE BATERÍAS RECARGABLES

Las baterías recargables son reciclables.

Usted podrá ayudar a conservar el medio ambiente devolviendo las baterías usadas al punto de reciclaje más cercano.

Para más información sobre el reciclado de baterías, visite <https://www.sony.com/electronics/eco/environmental-management>

Precaución: No utilice baterías recargables dañadas o con fugas.

No poner este producto cerca de aparatos médicos

Este producto (incluyendo los accesorios) tiene un imán (o imanes) que puede interferir con marcapasos, válvulas de derivación programables para el tratamiento de la hidrocefalia, o con otros aparatos médicos. No ponga el producto cerca de personas que utilicen dichos aparatos médicos. Consulte con su médico antes de utilizar este producto si utiliza cualquiera de dichos aparatos médicos.

Si tiene alguna pregunta acerca de este producto:

Visite: <https://www.sony.com/electronics/support>

Contacte con: Centro de servicio de información al cliente de Sony en 1-800-222-7669

Escríbala: Centro de servicio de información al cliente de Sony 12451 Gateway Blvd., Fort Myers, FL 33913

Declaración de conformidad del proveedor


Nombre comercial: SONY

Modelo: SRS-XB23

Parte responsable: Sony Electronics Inc.

Dirección: 16535 Via Espriilo, San Diego, CA 92127 EE.UU.

Número de teléfono: 858-942-2200



Precaución al cargar

Si la clavija USB se inserta estando húmeda, se producirá un cortocircuito debido a materias extrañas o líquidos (agua del grifo, agua salada, bebidas refrescantes, etc.) adheridos a la unidad principal o al cable de carga. Esto puede causar mal funcionamiento o sobrecalentamiento anormal.

No inserte nunca la clavija USB cuando la unidad principal o el cable de carga estén húmedos.

Precauciones

Seguridad

• Si su piel entra en contacto con este producto por un tiempo prolongado cuando está encendido, puede causar una lesión por temperatura baja.

• La información importante, como el nombre del modelo, se encuentra en las