


# Item: ELIB4C

## Assembly Instructions




Please visit our website for the most current instructions, assembly tips, to report damage or request parts. [www.walkerredison.com](http://www.walkerredison.com)


Revised 01/2024-V2

# General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver and hammer is required for the assembly of this product.



- VI. Power tools should not be used to assemble this product.




## VII. Maintenance Guide

To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.

1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.















# Parts List




Part #	Description	Qty
04	Bottom panel	01 pc
05	Shelf	02 pcs
06	Drawer slide	01 pc
07	Back panel	04 pcs
11	Drawer bottom	01 pc
18	Left drawer side	01 pc
21	Right drawer side	01 pc

Part #	Description	Qty
22	Right side panel	01 pc
23	Left side panel	01 pc
26	Foot	01 pc
28	Drawer front	01 pc
31	Top panel	01 pc
32	Drawer back	01 pc
33	Side rail	02 pcs

# Hardware List

A		ø8*40mm	Wooden dowel	02 pcs
B		ø10*20mm	Wooden dowel	06 pcs
C		ø4,0*40mm	Screw	06 pcs
D		ø3,5*30mm	Screw	04 pcs
E		Ø3,5*16m	Screw	02 pcs
F		ø8*8mm	Nail	16 pcs
G		ø15*12mm	Cam Lock	10 pcs
H		ø5,0*24mm	Cam Bolt	10 pcs
I		ø8*30mm	Wooden dowel	30 pcs
J		ø7,0*80mm	Screw	04 pcs
K		ø4,0*25mm	Screw	06 pcs
L		ø4,0*20mm	Screw	12 pcs
M			Handle	01 pc
N			Hex key	01 pc



Hammer recommended  
for assembly (not included)



Phillips head screwdriver required  
for assembly (not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Hardware List



O		ø26mm	Plastic fixing device	12 pcs
P		ø33mm	Cover	12 pcs
Q		ø30mm	Felt sticker	04 pcs

# Step 1


Insert wooden dowel ( I ) into parts 05, 26, 18, 21, 22, 23 and 31.



Please assemble on a clean soft surface to avoid damage.






Please assemble on a clean soft surface to avoid damage.




# Step 2



Insert wood dowel ( B ) into parts 06.



Attention to the dowel length: ø10\*20mm



# Step 3





O		12
ø26mm		


Insert Plastic fixing device (O) into parts 22, 23 and 31.

# Step 4

1 - Ensure cam bolt is installed straight and not at an angle.  
2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.



Insert Cam Bolts (H) with a Phillips head screwdriver into parts 22, 23 and 28.











## Step 5




Join the pieces firmly, avoiding an open gap between them.





Hold part 33 and attach the parts 22 and 23, tighten screw (L) with a Phillips head screwdriver.




## Step 6



Align the opening in cam lock to the cam bolt and press into opening. Using a screwdriver, rotate the cam lock until it engages with the cam bolt and locks in place (anywhere between 90-180 degrees). Do not over-tighten the cam lock. Doing so may result in damaged or broken parts.




Secure part 05 to part 23. Insert cam locks (G) into part 05 and tighten with a Phillips head screwdriver.





# Step 7



Join the pieces firmly, avoiding an open gap between them.








Hold part 33 in to part 31, tighten screw (L) with a Phillips head screwdriver.



# Step 8






Join the pieces firmly, avoiding an open gap between them.




Secure part 22 to part 05. Insert cam locks (G) into part 05 and tighten with a Phillips head screwdriver.

Hold part 33 into part 31 and tighten screw (L) with a Phillips head screwdriver.




G		03
ø15*12mm		
L		03
ø4,0*20mm		


## Step 9




Insert screw (J) into part 04 and 26,  
and tighten with hex key (N).





## Step 10



Secure part 04 in to parts 22, 23 with screw (C) and tighten with a Phillips head screwdriver.





# Step 11




Remove the felt sticker from the paper.  
Glue the felt to the bottom of the foot.

Insert part 07 into parts 22, 23, 04, 05. Fix with nail (F) and hammer.


F		16
Q		04

ø8\*8mm  
ø30mm

## Step 12




Secure parts 06 to parts 22 and 23 with screw (K) and phillips head screwdriver.







## Step 13



Secure parts 18 and 21 to part 28 using Cam Lock (G) and tighten with a Phillips head screwdriver.




## Step 14




Insert part 11 between parts 18 and 21.


## Step 15





Insert part 32 between parts 18 and 21. Secure part 32 to parts 18 and 21 with screw (D) and phillips head screwdriver.

D		04
$\varnothing 3,5 \times 30 \text{ mm}$		



## Step 16




Attach handle (M) with screw (E) and Phillips head screwdriver.

E		02
$\varnothing 3,5 \times 16$		
M		01

## Step 17







Insert wood dowel ( 1 ) into part (06) with hammer.




## Step 18

Insert wood dowel (A) on the inside of all drawers, with the drawer inside the unit after having passed the wood dowel that is in the drawer slide. The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.



## Step 19

Insert Cover (P) into Plastic fixing device (O) in the parts 22, 23 and 31.



## Step 20

## Assembly Complete!

