















CROSLEY

F U R N I T U R E






Storage Bench CF6041



PART LIST


A 	B 	C 	D 	E 
Top Panel 1 PC	Bottom Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Drawer Front Panel 1 PC
F 	G 	H 	I 	J 
Drawer Left Panel 1 PC	Drawer Right Panel 1 PC	Drawer Back Panel 1 PC	Drawer Bottom Panel 1 PC	Drawer Bottom Rail 1 PC
K 	L 	M 		
Back Panel 1 PC	Top Rail 1 PC	Cushion 1 PC		

HARDWARE LIST

#1 	#2 	#3 	#4 	#5 
Ø1/4"*1-1/8"	Ø8*30mm		Ø5/32"*1/2"	Ø4*25mm
Bolt 10 PCS (Extra 1)	Wood Dowel 10 PCS (Extra 1)	Handle 3 PCS	Round Head Bolt 6 PCS (Extra 1)	Screw 8 PCS (Extra 1)
#6 	#7 			
Ø3*10mm				
Round Head Screw 14 PCS (Extra 1)	Allen Wrench 1 PC			

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware"
Note: Be sure to check all hardware is locked when completed.

Step 1. Attach drawer bottom rail (part J), drawer left panel (part F) and drawer right panel (part G) to drawer front panel (part E) using wood dowel (part #2), screws (part #5), phillips head screwdriver and lock the hardware.




Step 2. Slide drawer bottom panel (part I) to assembled unit (parts E, F & G).


Attach drawer back panel (part H) to assembled unit (parts F, G, I & J) using wood dowel (part #2), screws (part #5), phillips head screwdriver and lock the hardware. Attach handles (part #3) to drawer front panel (part E) using round head bolts (part #4) and phillips head screwdriver.




Step 3. Attach top rail (part L) to top panel (part A) using bolts (part #1) and allen wrench (part #7).




Step 4. Attach panels (parts C & D) to top panel (part A) using bolts (part #1), wood dowels (part #2) and allen wrench (part #7).




Step 5. Attach bottom panel (part B) to assembled unit (parts C & D) using bolts (part #1), wood dowels (part #2) and allen wrench (part #7).



Step 6. Attach back panel (part K) to assembled unit (parts A, B, C & D) using round head screws (part #6) and phillips head screwdriver.



Step 7. Carefully turn unit upright. Slide assembled drawer into place.
 Note: To release trigger disconnect levers push one side up and the other down.



Step 8. Place cushion (part M) on top panel (part A).

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

