



**Item #: MI500TT / MI500TB**

**Description: MILA TABLE TOP/ TABLE BASE**

**Product Size: 42" x 60" x 78"H (18" Take Off Leaf)**

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

**Wood Furniture Maintenance:**

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

**The Enemies of Wood:**

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

**High Gloss Resin Table Maintenance:**

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

**Granite Top Maintenance:**

The surface of the granite on your table has been polished or sealed to create generally non-porous surface. The stone has many natural characteristic including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
  - \* Keeping them free of debris or sharp objects
  - \* Wiping up spills immediately
  - \* Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.
- Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

**Marble Top Maintenance:**

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

**Caring for the Fabric on Upholstered Furniture:**

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

## VERY IMPORTANT!!

**NEVER**

USE GLASS CLEANERS ON FINISHED SURFACES. AMMONIA WILL CHEMICALLY ATTACK THE FINISH.

DO NOT WRITE DIRECTLY ON SURFACE



PREVENT MARKING

DO NOT PLACE DIRECTLY IN SUNLIGHT



PREVENT FADING

DO NOT USE PLACEMATS WITH RUBBER BASES



PREVENT DISCOLORING

**NEVER**

ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION CAUSES THE WOOD TO WARP AND THE FINISH TO DE-LAMINATE.

DO NOT USE COMMERCIAL POLISHES AND WAXES



PREVENT YELLOWING

DO NOT PLACE HOT POTS, ETC. ON SURFACE



PREVENT DAMAGE TO FINISH!

REGULATE THE HUMIDITY CONDITIONS AT YOUR HOME



PREVENT SPLITTING


# MI500TT / MI500TB

## ASSEMBLY INSTRUCTIONS

P.2/4


**DO NOT FULLY TIGHTEN ALL BOLTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED**

### STEP 1:




**Step 1:** Attach the Mounting Plate (D) to the Table Base (C) by inserting Allen Bolt (1), Lock Washer (2), Flat Washer (3) into the holes of the Table Base (C) and tighten by Allen Key (4).

### STEP 2:







**Step 2:** Place the Table Top (A) upside down on the floor with a piece of cloth or carpet to prevent finish from scratching. Attach the assembly Table Base (C) in Step 1 to the Table Top (A) by inserting Allen Bolt (1), Lock Washer (2), Flat Washer (3) and tighten by Allen Key (4).

### STEP 3:







**Step 3:** Turn the table to the upright position. (\*Note: It is recommended to use two or more people to turn the table). Unlock the latch underneath the Table Top (A), and pull the Table Top (A) from both ends. Inserting the Table Leaf (B) in the middle of Table Top (A), close the Table Top (A) by pushing from both ends. Lock the latch underneath the Table Top (A) to prevent from sliding. Assembly of product is now completed.



## PART LIST

(A) TABLE TOP (1PC)	(B) TABLE LEAF (1 PC)
	
(C) TABLE BASE (2 PCS)	(D) MOUNTING PLATE (2 PCS)
	

### HARDWARE PACK # : PMI500TH

NO.	DESCRIPTION	DIMENSION	Q'TY
1	Allen Bolt		$\Phi 1/4"$ x 40 mm 16 pcs
2	Lock Washer		$\Phi 5/16"$ x 13 mm 16 pcs
3	Flat Washer		$\Phi 5/16"$ x 19 mm 16 pcs
4	Allen Key		4 mm 1 pc

# **PARTS FOR MI500TT / MI500TB** **COMPLETE HARDWARE # : PMI550TH**



## **PRODUCT DETAILS**

TOP	MDF/ASH VENEER
APRON	MDF/ASH VENEER
BASE	MDF/RUBBERWOOD VENEER/ MANGO WOOD
PRODUCT SIZE (TOP)	42" x 60"x78" w/18"H Take Off Leaf
PRODUCT SIZE (BASE)	9"x18"x28"H
CARTON SIZE (TOP)	63"x45"x5.5"H
CARTON SIZE (BASE)	20.87"x20.47"x29.72"H
NET WEIGHT (TOP)	103.4 LBS
NET WEIGHT (BASE)	84.7 LBS
GROSS WEIGHT (TOP)	114.4 LBS
GROSS WEIGHT (BASE)	91.3 LBS
CU.FT. (TOP)	9.02'
CU.FT. (BASE)	7.35'

**MADE IN VIETNAM**



**Item #: MI500A**

**Description: MILA ARM CHAIR**

**Product Size: 24" x 25" x 36" H**

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

#### Wood Furniture Maintenance:

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

#### The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

#### High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

#### Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
  - \* Keeping them free of debris or sharp objects
  - \* Wiping up spills immediately
  - \* Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

#### Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

#### Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

## VERY IMPORTANT!!

### NEVER

USE GLASS CLEANERS ON FINISHED SURFACES. AMMONIA WILL CHEMICALLY ATTACK THE FINISH.

DO NOT WRITE DIRECTLY ON SURFACE



PREVENT MARKING

DO NOT PLACE DIRECTLY IN SUNLIGHT



PREVENT FADING

DO NOT USE PLACEMATS WITH RUBBER BASES



PREVENT DISCOLORING

### NEVER

ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION CAUSES THE WOOD TO WARP AND THE FINISH TO DE-LAMINATE.

DO NOT USE COMMERCIAL POLISHES AND WAXES



PREVENT YELLOWING

DO NOT PLACE HOT POTS, ETC. ON SURFACE



PREVENT DAMAGE TO FINISH!

REGULATE THE HUMIDITY CONDITIONS AT YOUR HOME




PREVENT SPLITTING



# ASSEMBLY INSTRUCTIONS


DO NOT FULLY TIGHTEN ALL BOLTS AND HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED

## STEP 1:




Step 1 : Place Chair Back (A) on the floor. Attach Seat Box w/Seat Cushion (B) to the Chair Back (A) by inserting Big Flat Washer (4), Lock Washer (3), Long Bolt (1) into the holes at the rear corner block of the Seat Box w/Seat Cushion (B) and secure by Allen Key (7). Insert Big Flat Washer (4), Lock Washer (3), Short Bolt (2) into the rear bar of the seat frame. Tighten all bolts by Allen Key (7). Do not fully tighten.

## STEP 2:



Step 2: Attach Front Leg (C) to the Seat Box w/Seat Cushion (B) by inserting Big Flat Washer (4), Lock washer (3) and Hex Nut (5) through the bolts and secure by Hex Wrench (8). Do not fully tighten.


## STEP 3:



Step 3: Turn the Arm Chair to upright position. Attach the LSF /RSF Arm (D/E) to the Seat Box w/Seat Cushion (B) by using Big Flat Washer (4), Lock Washer (3), Short Bolt (2) and tighten with Allen Key (7).

Secure the LSF/RSF Arm (D/E) to the Chair Back (A) by using Small Flat Washer (6), Lock Washer (3), Short Bolt (2) and tighten with Allen Key (7). Do not fully tighten.

## STEP 4:








Step 4: Place Arm Chair on flat surface and adjust chair legs until level and chair does not wobble. Fully tighten all Bolts and Hex Nuts at this time. Insert Wood Plug (9) into the holes on Chair Back (A) as the picture shown.










Assembly of product is completed.

# PART LIST

P.3/4


(A) CHAIR BACK (1PC)		(B) SEAT BOX W/SEAT CUSHION (1PC)	
			
(C) FRONT LEG (2PCS)	(D) LSF ARM (1PC)	(E) RSF ARM (1PC)	
			

## HARDWARE PACK # : PMI500AH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Long Bolt		$\Phi 1/4"$ x 75 mm	4 pcs
2	Short Bolt		$\Phi 1/4"$ x 40 mm	9 pcs
3	Lock Washer		$\Phi 5/16"$ x 13 mm	17 pcs
4	Big Flat Washer		$\Phi 5/16"$ x 19 mm	15 pcs
5	Hex Nut		$\Phi 5/16"$ x 12 mm	4 pcs
6	Small Flat Washer		$\Phi 5/16"$ x 12 mm	2 pcs
7	Allen Key		4 mm	1 pc
8	Hex Wrench		12 mm	1 pc
9	Wooden Plug		$\Phi 13$ mm	2 pcs

# PARTS FOR MI500A

## COMPLETE HARDWARE # : PMI500AH



**FABRIC CONTENT : 100% POLYESTER FIBRE**

This fabric is not machine washable.

Allow +/- 3% residual shrinkage.

Do not use cleaning products containing brightening agents.

### PRODUCT DETAILS

CHAIR BACK  
SEAT BOX  
FRONT LEG  
ARM  
PRODUCT SIZE  
CARTON SIZE  
NET WEIGHT  
GROSS WEIGHT  
CU.FT.

RUBBER WOOD/ MANGO WOOD / ACACIA WOOD  
RUBBER WOOD/ MANGO WOOD / ACACIA WOOD  
ACACIA WOOD  
MANGO WOOD  
24." x 25" x 36" H  
45.47" x 21.65" x 14.17"H  
39.6 LBS / 2PCS  
48.4 LBS / 2PCS  
8.07' / 2PCS

**MADE IN VIETNAM**



# **Steve Silver Company Dining Chairs**

## **- Assembly Troubleshooting Guide**

The most important element of correct chair assembly is to tighten the bolts as directed. Prematurely tightening the bolts can lead to numerous issues and will lengthen the assembly time. Listed below are the most common issues in chair assembly and their easy solutions.

### **PROBLEM: Chair is unlevel.**

#### **Cause 1:**

Unlevel chairs can occur if the bolts are fully tightened before all bolts are attached. There is a variance in the alignment of this chair to allow the chair to be assembled more easily.

#### **Solution:**

Loosen each bolt in the seat box (front legs, back corner blocks and back apron) until they are finger tight. Place the chair upright on the floor. Sit in the chair for about 30 seconds. Carefully turn the chair upside down and tighten each bolt. The chair will now be level.

#### **Cause 2:**

Unlevel chairs can occur if one or more of the floor glides are missing from the bottom of the chair leg.

#### **Solution:**

Request a set of floor glides from the e-mail address below.

[AR@ssilver.com](mailto:AR@ssilver.com)

### **PROBLEM: Bolts do not fit properly.**

#### **Cause:**

This issue can occur when the bolts are tightened fully before all bolts are attached. There is a variance in the alignment of the bolts to allow the chair to be assembled more easily. Tightening the bolts prematurely can cause the holes for the other bolts to become slightly misaligned, causing the remaining bolts not to fit properly.

#### **Solution:**

Make sure each bolt in the seat box (front legs, back corner blocks and back apron) is loosened until finger tight. This will allow you to realign the holes, and the bolts will now fit properly.

### **Questions?**

Please call us at 1 800 344 7278, and we will be happy to help you.



**Item #: MI500S**

**Description: MILA SIDE CHAIR**

**Product Size: 21." x 24.5" x 36"H**

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

#### **Wood Furniture Maintenance:**

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

#### **The Enemies of Wood:**

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

#### **High Gloss Resin Table Maintenance:**

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

#### **Granite Top Maintenance:**

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
  - \* Keeping them free of debris or sharp objects
  - \* Wiping up spills immediately
  - \* Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

#### **Marble Top Maintenance:**

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

#### **Caring for the Fabric on Upholstered Furniture:**

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

## **VERY IMPORTANT!!**

### **NEVER**

USE GLASS CLEANERS ON FINISHED SURFACES. AMMONIA WILL CHEMICALLY ATTACK THE FINISH.

DO NOT  
WRITE  
DIRECTLY  
ON  
SURFACE



**PREVENT  
MARKING**

DO NOT  
PLACE  
DIRECTLY  
IN  
SUNLIGHT



**PREVENT  
FADING**

DO NOT  
USE  
PLACEMATS  
WITH  
RUBBER  
BASES



**PREVENT  
DISCOLORING**

### **NEVER**

ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION CAUSES THE WOOD TO WARP AND THE FINISH TO DE-LAMINATE.

DO NOT USE  
COMMERCIAL  
POLISHES  
AND WAXES



**PREVENT  
YELLOWING**

DO NOT  
PLACE HOT  
POTS, ETC.  
ON  
SURFACE



**PREVENT  
DAMAGE TO  
FINISH!**

REGULATE  
THE  
HUMIDITY  
CONDITIONS  
AT YOUR  
HOME




**PREVENT  
SPLITTING**

# MI500S

## ASSEMBLY INSTRUCTIONS


**DO NOT FULLY TIGHTEN ALL HEX NUTS AND BOLTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED**

### STEP 1:




**Step 1:** Place the Chair Back (A) on the floor. Attach Seat Box w/Seat Cushion (B) to Chair Back (A) by inserting Flat Washer (4), Lock Washer (3), Long Bolt (1) into the holes at the corner block of the Seat Box w/Seat Cushion (B). Insert Flat Washer (4), Lock Washer (3), Short Bolt (2) into the rear bar of the seat frame. Secure by Allen Key (6). Do not fully tighten.

### STEP 2:



**FINISH**




**Step 2:** Attach Front Leg (C) to the Seat Box w/Seat Cushion (B) by inserting Big Flat Washer (4), Lock washer (3), Hex Nut (5) and secure with Wrench (7). Do not fully tighten.

Turn the chair to upright position and place the chair on flat surface and adjust chair legs until level and does not wobble. Fully tighten all Bolts and Hex Nuts at this time.


Assembly of product is now completed.

## PART LIST


**(A) CHAIR BACK  
(1PC)**










**(B) SEAT BOX W/SEAT CUSHION  
(1PC)**



**(C) FRONT LEG  
(2PCS)**




### **HARDWARE PACK # : PMI500SH**

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Long Bolt		Ø 1/4" x 75 mm	4 pcs
2	Short Bolt		Ø 1/4" x 40 mm	3 pcs
3	Lock Washer		Ø 5/16" x 13 mm	11 pcs
4	Flat Washer		Ø 5/16" x 19 mm	11 pcs
5	Hex Nut		Ø 5/16" x 12 mm	4 pcs
6	Allen Key		4 mm	1 pc
7	Wrench		12 mm	1 pc

# PARTS FOR MI500S

## COMPLETE HARDWARE # : PMI500SH



**FABRIC CONTENT : 100% POLYESTER FIBRE**

This fabric is not machine washable.

Allow +/- 3% residual shrinkage.

Do not use cleaning products containing brightening agents.

### PRODUCT DETAILS

CHAIR BACK	RUBBER WOOD/ MANGO WOOD/ ACACIA WOOD/ PLYWOOD
SEAT BOX	RUBBER WOOD/ ACACIA WOOD
FRONT LEG	ACACIA WOOD
PRODUCT SIZE	21" x 24.5" x 36" H
CARTON SIZE	38.98" x 22.83" x 14.17"H
NET WEIGHT	37.4 LBS / 2PCS
GROSS WEIGHT	44 LBS / 2PCS
CU.FT.	7.30' / 2PCS

**MADE IN VIETNAM**

# **Steve Silver Company Dining Chairs**

## **- Assembly Troubleshooting Guide**

The most important element of correct chair assembly is to tighten the bolts as directed. Prematurely tightening the bolts can lead to numerous issues and will lengthen the assembly time. Listed below are the most common issues in chair assembly and their easy solutions.

### **PROBLEM: Chair is unlevel.**

#### **Cause 1:**

Unlevel chairs can occur if the bolts are fully tightened before all bolts are attached. There is a variance in the alignment of this chair to allow the chair to be assembled more easily.

#### **Solution:**

Loosen each bolt in the seat box (front legs, back corner blocks and back apron) until they are finger tight. Place the chair upright on the floor. Sit in the chair for about 30 seconds. Carefully turn the chair upside down and tighten each bolt. The chair will now be level.

#### **Cause 2:**

Unlevel chairs can occur if one or more of the floor glides are missing from the bottom of the chair leg.

#### **Solution:**

Request a set of floor glides from the e-mail address below.

[AR@ssilver.com](mailto:AR@ssilver.com)

### **PROBLEM: Bolts do not fit properly.**

#### **Cause:**

This issue can occur when the bolts are tightened fully before all bolts are attached. There is a variance in the alignment of the bolts to allow the chair to be assembled more easily. Tightening the bolts prematurely can cause the holes for the other bolts to become slightly misaligned, causing the remaining bolts not to fit properly.

#### **Solution:**

Make sure each bolt in the seat box (front legs, back corner blocks and back apron) is loosened until finger tight. This will allow you to realign the holes, and the bolts will now fit properly.

### **Questions?**

Please call us at 1 800 344 7278, and we will be happy to help you.





**Item #: MI500BNT / MI500BNB**

**Description: MILA BENCH TOP/ BENCH BASE**

**Product Size: 72"x 15" x 18" H**

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

#### **Wood Furniture Maintenance:**

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

#### **The Enemies of Wood:**

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

#### **High Gloss Resin Table Maintenance:**

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

#### **Granite Top Maintenance:**

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
  - \* Keeping them free of debris or sharp objects
  - \* Wiping up spills immediately
  - \* Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

#### **Marble Top Maintenance:**

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

#### **Caring for the Fabric on Upholstered Furniture:**

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

## **VERY IMPORTANT!!**

### **NEVER**

USE GLASS CLEANERS ON FINISHED SURFACES. AMMONIA WILL CHEMICALLY ATTACK THE FINISH.

DO NOT WRITE DIRECTLY ON SURFACE



**PREVENT MARKING**

DO NOT PLACE DIRECTLY IN SUNLIGHT



**PREVENT FADING**

DO NOT USE PLACEMATS WITH RUBBER BASES



**PREVENT DISCOLORING**

### **NEVER**

ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION CAUSES THE WOOD TO WARP AND THE FINISH TO DE-LAMINATE.

DO NOT USE COMMERCIAL POLISHES AND WAXES



**PREVENT YELLOWING**

DO NOT PLACE HOT POTS, ETC. ON SURFACE



**PREVENT DAMAGE TO FINISH!**

REGULATE THE HUMIDITY CONDITIONS AT YOUR HOME




**PREVENT SPLITTING**

# MI500BNT / MI500BNB

## ASSEMBLY INSTRUCTIONS


**DO NOT FULLY TIGHTEN ALL BOLTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED**

### STEP 1:




**Step 1:** Attach the Mounting Plate (C) to the Bench Leg (B) by inserting Allen Bolt (1), Lock Washer (2), Flat Washer (3) into the holes of the Bench Top (A) and tighten by Allen Key (4).

### STEP 2:



**Step 2:** Place Bench Top (A) upside down on the floor with a piece of cloth or carpet to underneath prevent finish from scratching. Attach the assembly Bench Leg (B) in Step 1 to the Bench Top (A) by inserting Allen Bolt (1), Lock Washer (2), Flat Washer (3) and tighten by Allen Key (4).


### STEP 3:




**Step 3:** Turn the Bench to upright position on flat surface. (\*Note: It is recommended to use two or more people to turn the table). Assembly of product is now completed.

## PART LIST


**(A) BENCH TOP  
(1PC)**







**(B) BENCH LEG  
(2 PCS)**




**(C) MOUNTING PLATE  
(2 PCS)**



### **HARDWARE PACK # : PMI500BNTH**

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Allen Bolt		$\Phi 1/4"$ x 40 mm	16 pcs
2	Lock Washer		$\Phi 5/16"$ x 13 mm	16 pcs
3	Flat Washer		$\Phi 5/16"$ x 19 mm	16 pcs
4	Allen Key		4 mm	1 pc

**PARTS FOR MI500BNT / MI500BNB  
COMPLETE HARDWARE # : PMI500BNTH**



**PRODUCT DETAILS**

SEAT	MDF/RUBBER WOOD
BENCH LEGS	VENEER/MANGO WOOD
PRODUCT SIZE	72" x15" x18"H
CARTON SIZE (SEAT)	75.19" x 17.52" x 3.74" H
CARTON SIZE (LEGS)	17.6"x 15.55"x 17.32" H
NET WEIGHT (SEAT)	44 LBS
GROSS WEIGHT (SEAT)	48.4 LBS
NET WEIGHT (LEGS)	33 LBS
GROSS WEIGHT (LEGS)	35.2 LBS
CU.FT (SEAT)	2.85'
CU.FT (LEGS)	2.74'

**MADE IN VIETNAM**



**Item #: MI500SV**  
**Description: MILA SERVER**  
**Product Size: 65" x 20" x 34.25" H**

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

**Wood Furniture Maintenance:**

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

**The Enemies of Wood:**

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

**High Gloss Resin Table Maintenance:**

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

**Granite Top Maintenance:**

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
  - \* Keeping them free of debris or sharp objects
  - \* Wiping up spills immediately
  - \* Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

**Marble Top Maintenance:**

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

**Caring for the Fabric on Upholstered Furniture:**

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

## VERY IMPORTANT!!

**NEVER**  
USE GLASS CLEANERS  
ON FINISHED SURFACES.  
AMMONIA WILL  
CHEMICALLY ATTACK  
THE FINISH.

DO NOT  
WRITE  
DIRECTLY  
ON  
SURFACE



**PREVENT  
MARKING**

DO NOT  
PLACE  
DIRECTLY  
IN  
SUNLIGHT



**PREVENT  
FADING**

DO NOT  
USE  
PLACEMATS  
WITH  
RUBBER  
BASES



**PREVENT  
DISCOLORING**

**NEVER**  
ALLOW LIQUIDS OF ANY  
KIND TO LINGER ON  
SURFACES. ABSORPTION  
CAUSES THE WOOD TO  
WARP AND THE FINISH  
TO DE-LAMINATE.

DO NOT USE  
COMMERCIAL  
POLISHES  
AND WAXES



**PREVENT  
YELLOWING**

DO NOT  
PLACE HOT  
POTS, ETC.  
ON  
SURFACE



**PREVENT  
DAMAGE TO  
FINISH!**


REGULATE  
THE  
HUMIDITY  
CONDITIONS  
AT YOUR  
HOME



**PREVENT  
SPLITTING**

# MI500SV

## ASSEMBLY INSTRUCTIONS




- Turn the Server (A) to upright position (\*Note: It is recommended to use two or more persons to turn the Server) . Place the Server on flat surface and adjust the Leveler under Legs until level and does not wobble.
- Open the Drawers and the Doors, remove the Handles by unfasten the Handle's Bolts and attach it to the outside of the Drawer and Doors by using secure by phillips-head screwdriver (not provided) as the picture shown.
- The Tipping Restraint (1) is stapled at the back of Server (A). Thread Tipping Restraint (1) through the slots of the Server (A) to fasten and lock as the picture shown. Assembly of product is now completed.



PART LIST

(A) SERVER  
(1 PC)




HARDWARE PACK # : PMI500SVH

NO.	DESCRIPTION		Q'TY
1	Tipping Restraint		1 Set

# PARTS FOR MI500SV

## COMPLETE HARDWARE # : PMI500SVH



### PRODUCT DETAILS

TOP	MDF/ ASH VENEER
APRON	RUBBER WOOD/ MANGO WOOD/ MDF ACACIA VENEER
DRAWER	MDF / ASH VENEER / PLY WOOD
SHELF	MDF / LOCAL VENEER
DOOR	MANGO WOOD/ TEMPERED GLASS
PRODUCT SIZE	65" x 20" x 34.25" H
CARTON SIZE	67.91" x 22.84" x 37" H
NET WEIGHT	187 LBS
GROSS WEIGHT	206.8 LBS
CU.FT.	33.21'

**MADE IN VIETNAM**