

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

183476 Wine Cabinet

REVISION 0: 21/12/2021

PAGE 01 OF 12

COASTERFURNITURE.COM

ITEM: 183476

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME 45 M

45 MINUTE

PARTS IDENTIFICATION

Α	FRONT FRAME	1PC	G BACK BRACE	1PC
В	BACK FRAME	1PC	H WINE RACK	1PC
			I BACK BOARD	1PC
С	LEFT FRAME	1PC	J DESK TOP	1PC
D	RIGHT FRAME MIDDLE PANEL	1PC	K SHELF PANEL	1PC
			L HANDLE	2PCS
E			M CASTER	2PCS
F	BOTTOM PANEL	1PC	N CASTER WITH LOCK	2PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




HARDWARE IDENTIFICATION

1	BOLT (1/4"x1/2" - BLK)	9PCS	6	WASHER (ø12mm - BLK)	32PCS
2	BOLT (1/4"x1-1/8" - BLK)	4PCS	7	WOONEN TENON (Ø8x30mm)	3PCS
3	BOLT (3/16"x1/2" - BLK)	28PCS	8	ALLEN WRENCH (4x22x60mm)	1PC
4	BOLT (3/16"x1-1/8" - BLK)	4PCS	9	WRENCH (14mm)	1PC
5	WASHER (¢12mm - BLK)	13PCS	10	PLASTIC STICK (14x20MM)	1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




ITEM: 183476


ASSEMBLY INSTRUCTIONS


STEP 3:



STEP 4:












ASSEMBLY INSTRUCTIONS

STEP 9:











ASSEMBLY INSTRUCTIONS










STEP 12:











Note: Dimension tolerance ±5%