










CROSLLEY

FURNITURE






Hall Tree CF6040



PART LIST


A 	B 	C 	D 	E 
Seat Panel 1 PC	Left Back Panel 1 PC	Right Back Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC
F 	G 	H 	I 	
Front Panel 1 PC	Back Panel 1 PC	Bottom Panel 1 PC	Support Bar 2 PCS	

HARDWARE LIST

#1	#2	#3	#4	#5
				
Cam Bolt	Cam Lock	Wood Dowel	Short Bolt	Long Bolt
8 PCS (Extra 1)	8 PCS (Extra 1)	20 PCS	20 PCS (Extra 1)	4 PCS
#6	#7	#8	#9	#10
				
$\phi 1/4"$	$\phi 1/4" \times 16\text{mm}$			$\phi 5/32 \times 19\text{mm}$
Spring Washer	Flat Washer	Handle	Knob	Round Head Bolt
24 PCS	24 PCS	2 PCS	4 PCS	8 PCS
#11	#12	#13	#14	#15
				
Left Spring Hinge	Right Spring Hinge	Round Head Screw	Pad	Bracket
1 PC	1 PC	8 PCS	2 PCS	1 PC
#16	#17	#18		
				
$\phi 3 \times 14\text{ mm}$				
Flat Head Screw	Allen Wrench	Safety Strap Kit		
8 PCS (Extra 1)	1 PC	1 SET		

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach handles (part #8) to front panel (part F) using round head bolts (part #10) and phillips head screwdriver.
Attach knobs (part #9) to back panels (parts B & C) using round head bolts (part #10) and phillips head screwdriver.




Step 2. Attach panels (parts D & E) to bottom panel (part H) using cam bolts (part #1), cam locks (part #2), wood dowels (part #3) and phillips head screwdriver.

Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible. Cam locks must rotate full 180°. See pictured insert.




Step 3. Attach assembled unit (parts D, E & H) to front panel (part F) using cam bolts (part #1), cam locks (part #2), wood dowels (part #3) and phillips head screwdriver. Secure assembled unit (parts D, E, F & H) using short bolts (part #4), spring washers (part #6), flat washers (part #7) and allen wrench (part #17).


Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible. Cam locks must rotate full 180°. See pictured insert.



Step 4. Attach support bars (part I) to back panel (part G) using short bolts (part #4), spring washers (part #6), flat washers (part #7) and allen wrench (part #17).




Step 5. Attach right back panel (part C) to assembled unit (parts G & I) using wood dowels (part #3), long bolts (part #5), spring washers (part #6), flat washers (part #7) and allen wrench (part #17).



#3  x 2
 #5  x 2
 #6  x 2
 #7  x 2
 #17  x 1


Step 6. Attach bracket (part #15) to back panels (parts B & C) using flat head screws (part #16) and phillips head screwdriver.

Attach left back panel (part B) to assembled unit (parts G & I) using wood dowels (part #3), long bolts (part #5), spring washers (part #6), flat washers (part #7) and allen wrench (part #17).



#3  x 2
 #5  x 2
 #6  x 2
 #7  x 2
 #15  x 1
 #16  x 2
 #17  x 1



Step 7. Secure assembled unit (parts B, C, G & I) using shorts bolts (part #4), spring washers (part #6), flat washers (part #7) and allen wrench (part #17).



- #4  x 6
- #6  x 6
- #7  x 6
- #17  x 1


Step 8. Attach assembled unit (parts D, E, F & H) to back panel (part G) using cam bolts (part #1), cam locks (part #2), wood dowels (part #3) and phillips head screwdriver. Secure assembled unit (parts D, E, F, G & H) using short bolts (part #4), spring washers (part #6), flat washers (part #7) and allen wrench (part #17).

Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible. Cam locks must rotate full 180°. See pictured insert.



- #1  x 2
- #2  x 2
- #3  x 6
- #4  x 4
- #6  x 4
- #7  x 4
- #17  x 1

Step 9. Attach seat panel (part A) to back panels (parts B & C) using flat head screws (part #16) and phillips head screwdriver.
Attach spring hinge (parts #11 & #12) to seat panel (part A) and panels (parts D & E) using round head screws (part #13) and phillips head screwdriver.




#11		x 1
#12		x 1
#13		x 8
#16		x 6

Step 10. Carefull turn the unit upright.

Attach pads (part #14) to the top edge of front panels (parts F).

Note: It is important to adjust levelers once fully assembled and upright.
Extend adjustable leveler until it's firmly in contact with the floor. If
relocating, adjust leveler as needed until it's firmly in contact with
the floor in new location.

Important: Safety strap kit (part #18) must be installed to prevent tipping,
damage and/or injury.



#14 ○ x 2

#18	A	B	C	D	E
					
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	5/8"x ϕ 3xD8 Short Screw 1 PC	1-1/2"x ϕ 4xD8 Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to left back panel (part B) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in left back panel (part B) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.

